

## Quick Installation Guide

### ■ Installation Instructions

1. Make sure that you have installed your Yale Smart Video Doorbell before you install the Doorbell Chime.
2. Attach the correct power module that you shall use.
3. Insert the Yale Doorbell Chime into a power outlet.
4. Once inserted, press the middle button on the side for around two seconds until you hear a pairing sound.
5. Now press the doorbell button on your Yale Smart Video Doorbell.
6. The Doorbell Chime is now paired with the Smart Video Doorbell.



### ■ How do I factory reset my Yale Doorbell Chime?

1. Make sure your Doorbell Chime is still inserted in your power outlet.
2. You can now reset the Doorbell Chime by pressing and holding the top button (with the music icon) for 10 seconds.
3. The Doorbell Chime will now restart and be back to factory settings.
4. It is now ready to be installed again (see above instructions)

