

PHILIPS
hue

Flux
Bracket for mounting
Support de fixation



iA

User manual
Benutzerhandbuch
Notice d'emploi
Manual de usuário
Manual do usuário
Manuale d'uso



hue

Signify

I.B.R.S. / C.C.R.I. Numéro 10461
5600 VB Eindhoven,
the Netherlands
00800-74454775

Signify North America Corporation
400 Crossing Blvd., Suite 600
Bridgewater, NJ 08807, USA

Signify Canada Ltd./Signify Canada Ltée.
281 Hillmount Road

Markham, ON, Canada L6C 2S3

Questions or Comments |

Questions ou commentaires : 1-800-555-0050

Importado y/o distribuido en México por:

Signify Mexico S.A. de C.V.

Av. La Palma No. 6, La Herradura, Huixquilucan,

Edo de México, C.P. 52784, México

RFC PME-620620-E84

Centro de contacto :

800-508-9000

www.philips-hue.com

442280037731

©2025 Signify Holding

All rights reserved

Last update: 09/2025




Incl.

iA




2




4 brackets per 1m/3,3ft/pi or more
4 support de fixation par 1 m/3,3 ft/pi ou plus

1a



1b



!



www.philips-hue.com/support