










MONTAGEANLEITUNG BENZIN-RASENMÄHER

EASY 4.20 P-S | 4.60 SP-S | 5.10 SP-S







	 EASY 4.20 P-S Art.-Nr. 113794	 EASY 4.60 SP-S Art.-Nr. 113795	 EASY 5.10 SP-S Art.-Nr. 113796
	(1350 x 480 x 1050) mm	(1580 x 570 x 1050) mm	(1610 x 570 x 1050) mm
	2,0 kW 2900 min ⁻¹	2,0 kW 2900 min ⁻¹	2,3 kW 2900 min ⁻¹
	ca. 21,8 kg	ca. 28,1 kg	ca. 31,8 kg
	42 cm	46 cm	51 cm
	30-75 mm	30 – 75 mm	30 – 75 mm
	ca. 50 l	ca. 60 l	ca. 60 l
	avhw = 8,16 m/s ² EN ISO 5395 K = 1,5 m/s ²	avhw = 8,16 m/s ² EN ISO 5395 K = 1,5 m/s ²	avhw = 7,51 m/s ² EN ISO 5395 K = 1,5 m/s ²
	L _{pA} = 84,5 dB(A) EN ISO 5395 EN ISO 11201 K = 3 dB(A)	L _{pA} = 81,7 dB(A) EN ISO 5395 EN ISO 11201 K = 3 dB(A)	L _{pA} = 84,6 dB(A) EN ISO 5395 EN ISO 11201 K = 3 dB(A)
	L _{wA} = 96 dB(A) EN ISO 3744	L _{wA} = 96 dB(A) EN ISO 3744	L _{wA} = 98 dB(A) EN ISO 3744

